



1. 185 System
2. 18mm Polyroof Approved Plywood / OSB3 (TG4)
3. Polyroof Pre-Formed GRP Drip Trim
4. Timber Support Batten
5. Ventilated Airspace (Min 50mm)
6. Glidevale FV250 Fascia Ventilator
7. Glidevale FV250 Gutter Bracket Spacer
8. Gutter
9. Fascia

NOTES

FV250 Fascia Ventilator is to be installed behind the gutter to allow ventilation to the roof void.

FV250 Gutter Bracket Spacer is to be fitted behind the gutter to ensure an unrestricted airflow into the ventilator and to ensure correct gutter position.

For further guidance please contact Polyroof Technical Services.



Title: Ventilated Drip

System: 185

Ref: 2.88

Scale: NTS
(Do Not Scale From Drawing)

Drawn: OM

Date: 03/02/17