



1. Substrate
2. Existing Waterproofing
3. Protec System
4. Aluminium Trim

NOTES

Aluminium trims are to be prepared and primed in accordance with the Polyroof Coatings Manual.

Apply proprietary filler to bridge all gaps including the junction of the fixing arm or trim joints.

To the aluminium trim joints apply Protec Resin and 75mm Protec Taping Mat to provide local reinforcement prior to the application of the main Protec system.

For further guidance please contact Polyroof Technical Services.



Title: Aluminium Trim Detail

System: Protec

Ref: 3.28

Scale: NTS
(Do Not Scale From Drawing)

Drawn: OM | Date: 10/05/16