



1. 185 System
2. Support Batten
3. Polyroof pre-formed GRP Drip Trim
4. 18mm Polyroof Approved Plywood / OSB3 (TG4)

NOTES

The drip trim should not sit tight against the fascia.

It may be prudent to incorporate a DPC or similar between the fascia and the drip trim. The DPC should be nailed to the plywood and dressed into the gutter to provide a secondary seal.

For further guidance please contact Polyroof Technical Services.



Ref: Drip Detail

System: 185

Project: 2.10

Scale: NTS
(Do Not Scale From Drawing)

Drawn: OM

Date: 31/01/17