



1. Weathering Flange / Seal
2. 185 System
3. Taping Mat Reinforcement
4. 18mm Polyroof Approved Plywood / OSB3 (TG4) Deck

NOTES

All right angles are to be strengthened by double taping. Disbondment tape may be required for any protrusion liable to significant movement.

Pipe must be abraded and solvent wiped and where required primed in accordance with the Polyroof coatings manual.

A flashing detail should be created with a weathering flange / seal. Flashing details are not covered by the Polyroof guarantee.

This detail may also be used for other small protrusions. Consult Polyroof Technical Services for further advice.

For further guidance please contact Polyroof Technical Services.



Title: Pipe / Protrusion Detail

System: 185

Ref: 2.11

Scale: NTS
(Do Not Scale From Drawing)

Drawn: OM

Date: 03/02/17