



1. Weathering flange / seal
2. Elastex SoLo membrane
3. Reinforced with Elastex SoLo Taping Mat

NOTES

- a. Right angle to be strengthened by double taping. Note: disbondment tape may be required for any protrusions liable to significant movement.
- b. Pipe must be abraded, solvent wiped, and, where required, primed, in accordance with the Polyroof coatings manual.
- c. A flashing detail should be created with a weathering flange/seal. Note that flashing details are not covered by the Polyroof guarantee.
- d. This detail may also be used for other small protrusions.

For further guidance please contact Polyroof Technical Services.



Ref: Pipe / Protrusion Detail

System: Elastex SoLo

Ref: 4.11

Scale: NTS
(Do Not Scale From Drawing)

Drawn: EM

Date: 07/19