



1. System taken into chase
2. Timber fillet
3. Elastex SoLo system
4. Substrate

#### NOTES

- a. As an alternative the system may be flashed with lead or GRP flashing.
- b. As per standard building practice, care must be taken when positioning the flashing as regards an cavity tray.
- c. Timber fillet may be omitted by double taping right angle junction.
- d. On completion the detail should be re-pointed or finished with PU sealant
- e. It is advised that wall flashings are periodically inspected

For further guidance please contact Polyroof Technical Services.



Ref: Wall Abutment

System: Elastex SoLo

Ref: 4.06

Scale: NTS  
(Do Not Scale From Drawing)

Drawn: EM

Date: 07/19